

1. Prepare counter top for installation by placing it upside down on a smooth surface.
2. Place undermount basin in the final position and make a mark around it using a marker.
3. Apply stone adhesive (liquid nail or similar) on the top edge of basin. See fig 1.
4. Attach basin to counter top using the threaded rods, L brackets, flat washers, spring washers, and wing nuts as shown in fig 1. Do not fully tight the wing nut at this step.
5. Use previous marking to align basin in the final position
6. Tighten wing nut and let adhesive dry.
7. If necessary, apply caulking in the inside of basin where it meets with the counter top.
8. Install counter top onto cabinet using silicone or similar adhesive. Check your alignments before allowing the adhesive to dry.

