



1. Drill two holes into the wall referring to the distance showed in figure A (75.6cm~29 3/4"), and insert anchors (4) into the drilled holes.
2. Assemble the slider (6) to the tube (5), and adjust the slider to a suitable position.
3. Remove wall bracket covers (1) from wall brackets (3) by sliding the casing out of the bracket.
4. Assemble the wall brackets(3) to the upper and lower part of the tube(6). Note: In this step you must decide on which side you want the hand shower to be.
5. Using the wall screws (2) provided, fix the wall brackets to the wall by tightening the screws.
4. Insert the wall bracket covers(1) back into the wall brackets.
5. For finished view refer to figure A.